



NOTES:

- 1: EACH ROW MARKER WILL HAVE THE SECTION AND ROW ENGRAVED ON EACH MARKER.
- 2: SECURE THE END OF A TAPE MEASURE TO THE ROW MARKER AND PULL THE TAPE OUT TO THE CORRESPONDING ROW MARKER AT THE OTHER END. THEN GO BACK TO THE START OF THE TAPE AND COUNT OFF EVERY 4'-2" (50 INCHES) TILL YOU REACH THE BURIAL PLOT YOU ARE SEARCHING FOR.
- 3: THE ROW MARKERS ARE LOCATED AT THE WEST EDGE OF THE BURIAL PLOT. WHEN DIGGING A BURIAL PIT PLEASE ALLOW A MIN. OF 18" AT THE WEST SIDE OF THE BURIAL PLOT FOR THE MONUMENT TO BE PLACED ON UNDISTURBED SOIL.
- 4: FOR BURIAL PLOTS THAT ARE LOCATED BETWEEN EXISTING BURIALS PULL THE TAPE FROM THE CENTER OF ONE MONUMENT TO THE CENTER OF THE OTHER MONUMENT THEN LOCATE THE NEW BURIAL PLOTS MAKING SURE NOT TO ENCROACH ON THE EXISTING BURIALS AND ALLOWING ENOUGH SPACE FOR ALL THE AVAILABLE PLOTS.